

Update: 20100121

| Brand | Model | BD-R Compatibility | | | Remark |
|-----------------|----------------------------|--------------------|-----|----------|--------|
| | | R2X | R4X | R6X | |
| Sony | BDP-BX1 | OK | OK | | |
| Sony | BDP-CX7000ES | OK | OK | | |
| Sony | BDP-CX960 | OK | OK | | |
| Sony | BDP-S1 | OK | OK | | |
| Sony | BDP-S1000ES | OK | OK | | |
| Sony | BDP-S2000ES | OK | OK | | |
| Sony | BDP-S300 | OK | OK | | |
| Sony | BDP-S350 | OK | OK | | |
| Sony | BDP-S360 | OK | OK | | |
| Sony | BDP-S500 | OK | OK | | |
| Sony | BDP-S5000ES | OK | OK | | |
| Sony | BDP-S550 | OK | OK | | |
| Sony | BDP-S560 | OK | OK | | |
| Sony | BDP-S760 | OK | OK | | |
| Sony | Playstation3 (120GB) | OK | OK | | |
| Sony | Playstation3 (40GB) | OK | OK | | |
| Sony | Playstation3 (80GB) | OK | OK | | |
| Panasonic (MEI) | DMP-70V | OK | OK | | |
| Panasonic (MEI) | DMP-BD10 | OK | OK | | |
| Panasonic (MEI) | DMP-BD10A | OK | OK | | |
| Panasonic (MEI) | DMP-BD10AK | OK | OK | | |
| Panasonic (MEI) | DMP-BD15 | OK | OK | | |
| Panasonic (MEI) | DMP-BD30 | OK | OK | | |
| Panasonic (MEI) | DMP-BD35 | OK | OK | | |
| Panasonic (MEI) | DMP-BD50 | OK | OK | | |
| Panasonic (MEI) | DMP-BD55 | OK | OK | | |
| Panasonic (MEI) | DMP-BD60 | OK | OK | | |
| Panasonic (MEI) | DMP-BD605K | OK | OK | | |
| Panasonic (MEI) | DMP-BD80 | OK | OK | | |
| Panasonic (MEI) | DMR-BS750 | OK | OK | | |
| Panasonic (MEI) | DMR-BS850 | OK | OK | | |
| Panasonic (MEI) | DMR-BW500 | OK | OK | | |
| Panasonic (MEI) | DMR-BW930 | OK | OK | | |
| SHARP | BD-HP16U | OK | OK | | |
| SHARP | BD-HP20S | OK | OK | | |
| SHARP | BD-HP20U | OK | OK | | |
| SHARP | BD-HP21U | OK | OK | | |
| SHARP | BD-HP22U | OK | OK | | |
| SHARP | BD-HP50 | OK | OK | | |
| SHARP | DV-BP1 | OK | OK | | |
| HLDS | BD-300 | OK | OK | | |
| HLDS | BD-370 | OK | OK | | |
| HLDS | BD-390 | OK | OK | | |
| HLDS | BH-100 | OK | OK | | |
| HLDS | BH-200 | OK | OK | | |
| Sharp | BD-HDW15 | OK | OK | OK | |
| Sharp | BD-HDW20 | OK | OK | OK | |
| Sharp | BD-HDW22 | OK | OK | OK | |
| Sharp | BD-HDW25 | OK | OK | OK | |
| Sharp | BD-HDW30 | OK | OK | OK | |
| Sharp | BD-HD22 | OK | NS | NS | |
| Sharp | BD-HDV22 | OK | OK | OK | |
| Sharp | BD-HDW32 | OK | NS | NS | |
| Sharp | BD-HDW35 | OK | NS | NS | |
| Sharp | BD-HDW40 | OK | NS | NS | |
| Sharp | BD-HDS32 | OK | NS | NS | |
| Sharp | BD-HDW43 | OK | NS | NS | |
| Sharp | BD-HDW45 | OK | NS | NS | |
| Sharp | BD-HDW50 | OK | NS | NS | |
| Sharp | BD-HDS43 | OK | NS | NS | |
| Sharp | AQUOS DX1 | OK | OK | Feb'2010 | |
| Sharp | AQUOS DX2 | OK | OK | Mar'2010 | |
| Samsung | BD-P1600 (2009 HH model) | NA | OK | OK | |
| Samsung | BD-P4600 (2009 Slim model) | NA | OK | OK | |